L.U.C.A.S 600 System Connection Guide

SSL HIRE

REMEMBER
Turn amplifier on last, but off first..!

Never unplug ANY leads when the system is in use.

Limit Indicator Avoid RED

Limit Indicator Avoid RED

Subwoofer Volume Set To 12 o'clock

Loudspeaker Volumes Set To Full (LEFT & RIGHT)

This is where your DJ Console or Sound Mixer plugs in (LEFT)

This is where your DJ Console or Sound Mixer plugs in (RIGHT)

This is where you plug in the power connector.

This is where the loudspeaker lead is connected (LEFT)

This is where the loudspeaker lead is connected (RIGHT)

Turn on/off switch